



Timbersled Products, Inc.
416 Larkspur St.
Ponderay, ID 83852

Web Site: www.timbersled.com
E-mail: info@timbersled.com
Phone: (208) 255-5644
Fax: (208) 255-5924

Timbersled Mtn. Horse Snow Bike System **Tunnel Top Reinforcement Plate Instructions:**

Installation:

1. Remove the Timbersled sticker from the tunnel top.
2. Remove 2 rear bolts that hold the tunnel top to the rear bumper handle. This requires a 4mm Allen wrench. The bolts have lock-tite on them so they may be pretty tight.
3. Place the reinforcement plate on top of the tunnel and reinstall the 2 bolts. Use blue lock-tite on the bolts. Make sure the plate is lined up with the back of the tunnel top before tightening the bolts.
4. Drill the 5 holes through the plate and the tunnel top using a sharp 3/16" drill bit.
5. Install the pop rivets into the holes making sure to press the two pieces together as you secure the rivet.
6. Place the new Timbersled sticker on the tunnel top.

